

Visualizing Data on Cooley with ParaView

Joseph Insley

Lead, Visualization & Data Analysis
Argonne Leadership Computing Facility

Silvio Rizzi

Assistant Computer Scientist
Argonne Leadership Computing Facility

Janet Knowles

Principal Software Engineering Specialist
Argonne Leadership Computing Facility

Software for visualization hands on session

If you would like to follow along the visualization hands on activities, we recommend that you download and install ParaView version 5.8 in advance.

Please point your browser to <https://www.paraview.org/download/>

- **Windows**

Download and install `ParaView-5.8.0-Windows-Python3.7-msvc2015-64bit.exe`

Note: if you find an error about `VCOMP140.DLL`, there is a possible solution here

<https://discourse.paraview.org/t/missing-dll/3650>

- **Linux**

Download and untar `ParaView-5.8.0-MPI-Linux-Python3.7-64bit.tar.gz`

- **macOS**

Download and install `ParaView-5.8.0-MPI-OSX10.12-Python2.7-64bit.dmg`

Where to get it...

ParaView

- www.paraview.org

A version of this tutorial

- www.alcf.anl.gov/user-guides/vis-paraview-red-blood-cell-tutorial

Download data

- web.alcf.anl.gov/visinternal/MISC/BLOODFLOW_ANIMATION_DATA.tar.gz
(272MB/390MB)
- web.alcf.anl.gov/visinternal/MISC/BLOODFLOW_ANIMATION_DATA_SMALL.tar.gz
(136MB/195MB)
- Available on Cooley:
 - `/lus/theta-fs0/projects/Comp_Perf_Workshop/visualization/DATA/BLOODFLOW_TUTORIAL_DATA`

More Information


Online Help – **F1** 
The ParaView User's Guide
– www.paraview.org/paraview-guide

The ParaView web page

– www.paraview.org




ParaView Discourse Support Forum

– discourse.paraview.org



Goals

- Tour of ParaView
- Launch ParaView in Client/Server mode on Cooley
- Show range of visualization methods
- Feel for ParaView “way”
- Scripting and running in batch mode




Data

- Blood flow simulation data
- Multiple data types
 - Continuum data field (unstructured mesh, tetrahedral)
 - Particle data (unstructured points)
 - Red Blood Cells (RBC, polygonal mesh, triangles)
- Generated using NekTar/LAMMPS simulation code
- Courtesy of George Karniadakis and Leopold Grinberg of Brown University

ParaView Architecture

- Three tier
 - Data Server
 - Render Server
 - Client


Standalone



ParaView Architecture

- Three tier
 - Data Server
 - Render Server
 - Client


Client-Server



ParaView Architecture

- Three tier
 - Data Server
 - Render Server
 - Client

Client-Render Server-Data Server



ParaView on Cooley / Theta

Version 5.8.0 on Cooley

Version 5.7.0 on Theta

(Client and Server versions must match)

- On Cooley, add the following to your .soft.cooley file (before @default):

@paraview-5.6.1

ParaView on Cooley / Theta


Version 5.8.0 on Cooley

Version 5.7.0 on Theta

(Client and Server versions must match)

After launching client locally

- **Connect**
- Fetch servers (first time only)
- Fetch Cooley configuration
- Connect
- Configure server settings
- Connecting: Enter Password
- Open File



ParaView on Cooley / Theta


Version 5.8.0 on Cooley

Version 5.7.0 on Theta

(Client and Server versions must match)

After launching client locally

- Connect
- **Fetch servers (first time only)**
- Fetch Cooley configuration
- Connect
- Configure server settings
- Connecting: Enter Password
- Open File



ParaView on Cooley / Theta


Version 5.8.0 on Cooley

Version 5.7.0 on Theta

(Client and Server versions must match)

After launching client locally

- Connect
- Fetch servers (first time only)
- **Fetch Cooley configuration**
- Connect
- Configure server settings
- Connecting: Enter Password
- Open File



Configuration Name	Server	Source
RHEA@ORNL		Kitware Inc.
windows to RHEA@ORNL		Kitware Inc.
TITAN@ORNL		Kitware Inc.
windows to TITAN@ORNL		Kitware Inc.
COOLEY@ANL		Kitware Inc.
windows to COOLEY@ANL		Kitware Inc.
THETA@ANL		Kitware Inc.
windows to THETA@ANL		Kitware Inc.
EDISON@NERSC		Kitware Inc.
windows to EDISON@NERSC		Kitware Inc.

Edit Sources Import Selected Cancel

ParaView on Cooley / Theta


Version 5.8.0 on Cooley

Version 5.7.0 on Theta

(Client and Server versions must match)

After launching client locally

- Connect
- Fetch servers (first time only)
- Fetch Cooley configuration
- **Connect**
- Configure server settings
- Connecting: Enter Password
- Open File



ParaView on Cooley / Theta

Version 5.8.0 on Cooley

Version 5.7.0 on Theta

(Client and Server versions must match)

After launching client locally

- Connect
- Fetch servers (first time only)
- Fetch Cooley configuration
- Connect
- [Configure server settings](#)
- Connecting: Enter Password
- Open File

Connection Options for "COOLEY@ANL"

Xterm executable

SSH executable

Remote machine

Username

ParaView version

Client port

Server port

Number of nodes to reserve

Number of minutes to reserve

Account

Queue

Job name

ParaView on Cooley / Theta


Version 5.8.0 on Cooley

Version 5.7.0 on Theta

(Client and Server versions must match)

After launching client locally

- Connect
- Fetch servers (first time only)
- Fetch Cooley configuration
- Connect
- Configure server settings
- **Connecting: Enter Password**
- Open File



ParaView on Cooley / Theta


Version 5.8.0 on Cooley

Version 5.7.0 on Theta

(Client and Server versions must match)

After launching client locally



- Connect
- Fetch servers (first time only)
- Fetch Cooley configuration
- Connect
- Configure server settings
- Connecting: Enter Password
- Open File




Path: */lus/theta-fs0/projects/Comp_Perf_Workshop/visualization/DATA/BLOODFLOW_TUTORIAL_DATA*

Load Multi-component Dataset

- Pipeline Browser
 - Click **Apply**
- Default values will result in:



User Interface




Simple Camera Manipulation

- Drag left, middle, right buttons for rotate, pan, zoom.
- Also use Shift, Ctrl modifiers.
- Hold down x, y, or z key to constrain rotation to a specific axis




Select which data to view

- Hide data sets with **Eyeball icon**
 - Black (Open) == visible
 - Grey (Closed)== hidden
- Select **artery_step_000*** in the Pipeline Browser
 - Click on the name to highlight it
- When manipulating appearance or applying filters, these always affect the selected data set




Display Properties




Advanced Properties

Data Representation




Manipulating the color map

- Under Coloring click **Edit**



- Click favorites icon
- Select a Preset
 - Default / All dropdown
- Click Apply



Undo Redo



Undo



Redo





Camera
Undo



Camera
Redo

Data Representation

- Under Properties: **Representation** dropdown, select **Wireframe**



Common Filters



Calculator



Contour



Clip



Slice



Threshold



Extract Subset



Glyph



Stream Tracer



Warp (vector)





Group Datasets



Extract Level



Generate Streamlines

- Make sure artery_step_00* is selected in the Pipeline Browser
- Main menu: Filters-> Alphabetical->Stream Tracer
- Seeds: **Seed Type** to **High Resolution Line Source**.
- Click the **Y Axis** button
- **Resolution: 25**.
- Apply






Streamlines as Tubes

- With StreamTracer1 selected: Filters-> Alphabetical->Tube
- Radius: 0.1
- Apply
- Coloring: Velocity





Streamlines as Tubes

- With StreamTracer1 selected: Filters-> Alphabetical->Tube
- Radius: 0.1
- Apply
- Coloring: Velocity
- Render Lines As Tubes
- Line Width: 4




Cutting Planes (Slices)

- `artery_step_000*` selected in the Pipeline Browser
- Filters->Alphabetical->Slice
- Click **Gear Icon**
- Value Range: **Delete All**
- **New Range**
- **Steps: 7**
- Uncheck: **Show Plane**





Cutting Planes (Slices)

- Color by: Velocity




Data representation: Opacity

- **artery_step_000*** selected in the Pipeline Browser
- Properties: Styling
- **Opacity: 0.2**



Animating Simulation Data

- **Play** button on the animation bar at the top of the GUI
- **Pause** to stop
- **Loop**: Repeat animation until stopped





Save Screenshot

1. Choose File →  Save Screenshot...
2. Complete the following dialogs.


Save Animation

1. File-> Save Animation
2. Animation Settings Dialog: **Save Animation**
3. **Files of type:**
 - AVI
 - PNG




Saving ParaView State

1. Choose File → Save State...
 - .pvsm (for restoring state in interactive mode)
 - saved on the client side
2. Edit → Reset Session 
3. Choose File → Load State...
4. Load State Options
 1. Use File Names From State
 2. Search files under specified directory
 3. Choose File Names






Enter: Red Blood Cells

- Unhide good_rbc_step_000* and bad_rbc_step_000*



Using color to differentiate data

- Select one of the rbc data sets in the Pipeline Browser
- **Coloring: Solid Color**
- **Edit**
- Pick different colors for the two data sets




Saving ParaView State and Scripting

1. Choose File → Save State...

- .py (for use with pvbatch)
 - any *modified* properties
 - all properties
- saved on the client side

2. Edit .py script

- short example, loop over time steps, saving images in batch mode



Saving ParaView State and Scripting

At the top of the script:

```
import sys
start_frame=int(sys.argv[1])
num_frames=int(sys.argv[2])
IMAGE_DIR = "/path/to/where/we/should/save/images/
```

At the bottom of the script:

```
RenderView1.ViewSize = [1920, 1080]           # set resolution appropriately
time_vals = artery\_step\_0000vtu.TimestepValues # find data reader object
for i in range(start_frame, start_frame+num_frames):
    RenderView1.ViewTime = time_vals[i]
    RenderView1.StillRender()
    IMAGE_FILE="%s/frame_%04d.png" % (IMAGE_DIR, i)
    print ("saving: " + IMAGE_FILE)
    WriteImage(IMAGE_FILE)
```

Saving ParaView State and Scripting

- Copy python script to Cooley
- Submit batch job to render animation
 - `qsub -n 1 -t 60 -A Comp_Perf_Workshop -q training2 /soft/visualization/paraview/v5.8.0/bin/pvbatch python_script.py 0 50`
 - `qsub -n 1 -t 60 -A Comp_Perf_Workshop -q training2 /soft/visualization/paraview/v5.8.0/bin/pvbatch python_script.py 50 50`
- Encode frames using ffmpeg
 - `soft add +ffmpeg`
 - `ffmpeg -r 25 -i /path/frame_%04d.png -r 25 -pix_fmt yuv420p movie_01.mp4`

Particles as Glyphs



- First need to add a Calculator Filter
- (this seems to be a bug with glyphs and vector data arrays)
- Select particles.000*
- Apply Calculator filter
- Set equation to **Velocity**



Apply Reset Delete ?

Search ... (use Esc to clear text)

Properties (Calculator1)

Attribute Type: Point Data

☐ Coordinate Results

☐ Result Normals

☐ Result TCoords

Result Array Name: velocity vec

Velocity

Clear	()	iHat	jHat
sin	cos	tan	abs	sqrt
asin	acos	atan	ceil	floor
sinh	cosh	tanh	x^y	exp
v1.v2	mag	norm	ln	log10

Scalars Vectors

☒ Replace Invalid Results



Replacement Value: 0

Result Array Type: Float

Particles as Glyphs





- With Calculator1 selected in Pipeline Browser
- Filters->Alphabetical->Glyph
- **Glyph Type: Sphere**
- **Orient: Unchecked** (optional)
- Scale Mode: off
- **Set Scale Factor: 0.35**
- **Glyph Mode: Every Nth Point**
- Stride: 10



Finalizing Glyphs

- Hide the Calculator1: Eye icon in Pipeline Browser
- Color Glyph1 by: Velocity



Making it Look Pretty

- Ray Traced Rendering
 - Enable Ray Tracing
 - Shadows
 - Samples Per Pixel
 - Denoise
 - Light Scale

Ray Traced Rendering

☒ Enable Ray Tracing

☒ Shadows

Back End

OSPRay raycaster

Ambient Samples

0

Samples Per Pixel

4

Progressive Passes

1


☒ Denoise

Light Scale


1.25

Temporal Cache
Size

0



Making it Look Pretty



QUESTIONS?

Joe Insley
insley@anl.gov

Silvio Rizzi
srizzi@anl.gov

Janet Knowles
jknowles@alcf.anl.gov